

EPSON GrayBalancer/EPSON Printer Service Utility Installation Guide

EPSON GrayBalancer

Windows:

1. Insert the EPSON GrayBalancer/EPSON Printer Service Utility Set Up CD-ROM in your CD-ROM drive.
2. The EPSON folder opens automatically. If the EPSON folder does not appear, click Start and Run. Then, type D: and click OK. Substitute the appropriate letter for your CD-ROM drive as necessary.
3. Double-click the EPSON GrayBalancer folder.
4. Double-click the language folder you want.
5. Double-click Setup.exe, and follow any on-screen instructions to install the utility.

Macintosh:

1. Insert the EPSON GrayBalancer/EPSON Printer Service Utility Set Up CD-ROM in your CD-ROM drive.
2. The EPSON folder opens automatically. If the EPSON folder does not appear on your desktop, double-click the EPSON icon on your desktop.
3. Double-click the EPSON GrayBalancer folder.
4. Double-click the language folder you want.
5. Double-click the Installer icon, and follow any on-screen instructions to install the utility.

EPSON Printer Service Utility

Windows:

1. Insert the EPSON GrayBalancer/EPSON Printer Service Utility Set Up CD-ROM in your CD-ROM drive.
2. The EPSON folder opens automatically. If the EPSON folder does not appear, click Start and Run. Then, type D: and click OK. Substitute the appropriate letter for your CD-ROM drive as necessary.
3. Double-click the EPSON Printer Service Utility folder.
4. Double-click Setup.exe, and follow any on-screen instructions to install the utility.

Macintosh:

1. Insert the EPSON GrayBalancer/EPSON Printer Service Utility Set Up CD-ROM in your CD-ROM drive.
2. The EPSON folder opens automatically. If the EPSON folder does not appear on your desktop, double-click the EPSON icon on your desktop.
3. Double-click the EPSON Printer Service Utility folder.
4. Double-click the Installer icon, and follow any on-screen instructions to install the utility.